


INSTALLATION INSTRUCTIONS FOR THE C6 CORVETTE REAR VIEW MIRROR


1 - To release the tension of the spring clip, simply squeeze the TRIGGER and the back side of the mount together. This will lower the bottom portion of the spring clip allowing you to slide the radar detector RD on and off. When used properly, the spring clip avoids putting excessive pressure on the mirror stem when installing and removing the RD. **The top portion of the mount should barely move when the two opposing forces are applied. SLIDE THE RD ONTO THE SPRING CLIP AS FAR AS IT WILL GO.** Release the trigger to secure the RD onto the mount. Before installing the mount onto your rear view mirror, remove and install the RD a few times so you can observe how the spring clip functions.



2 - Observe the illustration above which identifies the components of the mount. Remove the Spring Clip by removing both Pinch Plate Screws.



3 - IMPORTANT- Observe the two Clamp Screws that are accessible through the slots of the Rotating Adjustment Plate. Before installing the mount, insert the supplied allen wrench into the heads of the Clamp Screws to make sure they are accessible.



4 - This photo illustrates how the Hook fits into the recessed area behind the mirror. This is just a reference photo as you will not be able to see this during installation.



5 - Place the Windshield Pad onto the Silicone Pad. Position the mount as shown above. Compress the Silicone Pad into the Windshield Pad as you slide upwards into the recessed area behind the mirror. You will hear the Hook snap into place when it is positioned correctly as shown in fig. 6.



6 - Tighten the two Clamp Screws (identified in fig. 3), alternating from one to the other every two or three revolutions. You will notice a little resistance once the Rubber Pad starts compressing against the bottom of the mirror. Make sure that both Clamp Screws are tight. Reattach the Spring Clip the Pinch Plate.



8 - Install the RD onto the mount making sure it locks onto the Spring Clip. Make the necessary adjustments as shown. We recommend adjusting the RD so it is as close to the bottom of the mirror as possible. There may not be enough room for your finger to fit between the RD and the mirror, however the spring clip allows you to move the RD downward with one finger while pressing the RD buttons with another finger. The RD will return to its original position when released. After all adjustments are made, be sure to check that all adjustment screws are tight. Grab the long arm of the allen wrench to assure that these screws are securely tightened.



9 - We recommend installing the 3/4" diameter Support Pad between the mirror and the RD for additional stability. There are three different thicknesses included depending on the gap between the RD and the mirror after all adjustments are made.

CAUTION

DO NOT use this mount if it interferes with the adjustability or the operation of your rear view mirror in any way.

DO NOT use this mount if the radar detector creates an unsafe viewing obstruction.

DO NOT ATTEMPT TO MODIFY THIS PRODUCT. Consult the manufacturer for assistance.

All BlendMount products are accompanied with detailed installation instructions and adjustment tips. You are encouraged to contact customerservice@blendmount.com or call J28 Design at 1-888-497-8388 for further assistance.

Check the BlendMount Forum for installation tips and some vehicle specific installs.

www.blendmount.com

Your feedback is very important to us. Please email any questions or comments you have to customerservice@blendmount.com



**Innovative Design And
Precision Manufacturing**

BlendMount - US PATENT # D625,580 S, D656,811 S, D653,980 S, D690,245 S, D690,246 S, D690,247 S and other patents pending